AVSWITCH-60 &
AVSWITCH-60S

4 Port Luxury HDMI Switch




MANUAL

ENGLISH


Connections:

Front side:



1) On/Off button
2) IR Remote Sensor
3) LCD Display
4) Joystick
   Edit Source name
5) Source button / Gain adjustment
   Toggle from Input 1-> Input 4


Back side:



6) HDMI Jack
7) Optical Jack
8) Power Jack

Remote Control:

9) On/Off button
10) Gain Control " - & + "
11) Source Control " - & + "
12) Source Control 1 ~ 4



Gain Control:


Due to variance in quality, types and lengths of HDMI cables, this switch features a gain control.
This feature provide perfect video quality when it appears ”snowy” or “rainy”.

You may change gain via the bellowing operation to get perfect HD-video and audio

a) Press remote control: Gain+, Gain-
b) Gain Operation on the front panel:
1) Press and hold “ SELECT” for 3 seconds;
2) You will find text “Gain 6” on the display;
3) Press UP/DOWN on Joystick to increase/decrease gain number;
4) Push Joystick to finish the setup;
Note: Gain adjustment range: 0~15; default value: 6.

Display customization:

This switch allows you to customize the names of the sources you have connected. To edit the names of the sources, follow the instructions below.



SAFETY PRECAUTIONS:
To reduce risk of electric shock, this product should ONLY be opened by an authorized technician if service is required. Disconnect the product from mains and other equipment if a problem should occur. Do not expose the product to water or moisture.

WARRANTY:
No guarantee or liability can be accepted for any changes and modifications of the product or damage caused due to incorrect use of this product.

GENERAL:
Designs and specifications are subject to change without a notice.

WWW.HQPRODUCTS.COM